

**TO OBTAIN EXACT LOCATION FOR AN “R” PANEL
AND STANDING SEAM ROOF:**

1. Always stand downslope of opening, looking upslope.
2. Determine centerline of opening.
3. Measure left or right of centerline to the centerline of the nearest lap joint or natural seam in roof.
4. Measure centerlines of standing seams at the curb locations.
5. Determine outside dimension of curb.
6. Determine roof slope, type of panel (“R”, Standing Seam, etc.).
7. If existing roof panel, go to eave of roof and trace off the profile of two highs and the flat between.
8. Fax above information to David Funderburk @ 903/759-0879.
9. All the above information will be compiled into a roof curb drawing and faxed back to you for field verification.
10. After field verification, return via fax to LMCurbs one copy of each drawing marked “Approved for Fabrication” along with your purchase order, shipping address, tax exemption certificate, and required delivery.

**NOTE: ABOVE INFORMATION IS FOR GUIDELINE ONLY; ALL REQUIREMENTS
MAY NOT PERTAIN TO YOUR SITUATION.**