



Air Barrier and Thermal protection for purlin/eave strut void caused when using top of purlin insulation system and liner or filled cavity system in walls

- Insulation
- Additional insulation (if needed)
- Double Faced Tape or adhesive
- Wall Sheet
- 6" Faced Fiberglass
- Roof Facing
- Thermal Break Tape
- Liner System Fabric or Filled Cavity facing

Bay Insulation Systems
 2929 Walker Drive
 Green Bay, WI 54308

NOT to Scale